

Grandstream Networks, Inc.

DP760

User Manual



DP760 - User Manual

WELCOME

The DP760 is a powerful DECT Repeater that auto associates to Grandstream DP750 Base Station to offer extended mobility to business and residential users. It extends an additional range of 300 meters outdoors and 50 meters indoors to give users the freedom to move around their work or home space, delivering efficient flexibility. This DECT Repeater relays up to two concurrent HD calls. The Ethernet connection provides PoE for convenient installation and variety of remote features including provisioning, status monitoring and firmware upgrade. When paired with Grandstream DP750 DECT VoIP base station and DP720 handsets, the DP760 is a powerful DECT Repeater that allows any business or residential user to create a cordless VoIP solution of extended coverage.

PRODUCT OVERVIEW

Feature Highlights

The following table contains the major features of the DP760:

 <p>DP760</p>	<ul style="list-style-type: none">• 5 Stations in star.• 2 Concurrent HD calls.• PoE power support.• 300m range outdoor / 50m range indoor.• Automatic or manual association to base station.
---	---

DP760 Features at a Glance

DP760 Technical Specifications

The following table resumes all technical specifications including the protocols / standards supported, voice codecs, telephony features, languages and upgrade/provisioning settings for DP760 DECT Repeater.

Air Interface	<p>Telephony standards:</p> <ul style="list-style-type: none"> ◦ DECT EN 301 406:2001 ◦ DECT GAP TBR22 EN 300 444:2001 ◦ DECT DECT EN 300 700 ◦ CAT-iq TS 102 527 <p>Frequency bands:</p> <ul style="list-style-type: none"> ◦ 1880 – 1900 MHz (Europe) ◦ 1920 – 1930 MHz (US) ◦ 1910 – 1920 MHz (Brazil) <p>Number of channels: 10 (Europe), 5 (US, Brazil).</p> <p>Range: up to 300 meters outdoor and 50 meters indoor.</p>
Peripherals	<p>5 LED indicators: Power, Network, Association, Activity, DECT</p> <p>Reset button, Pairing/Paging button</p> <p>One 10/100 Mbps auto-sensing Ethernet port with integrated PoE</p>
Protocols/Standards	<p>TCP/IP/UDP, HTTP/HTTPS, ARP/RARP, ICMP, DNS (A record, SRV, NAPTR), DHCP, PPPoE, SSH, TFTP, NTP, SIMPLE, LLDP-MED.</p>
Voice Codecs	<p>G.722 codec for HD audio and G.726 codec for narrow band audio.</p>
Telephony Features	<p>Plug-n-Play, auto association, auto region detection and seamless call handover.</p>
Security	<p>User and administrator level access control, MD5 and MD5-sess based authentication, 256-bit AES encrypted configuration file, HTTPS, 802.1x media access control, DECT authentication.</p>
Multi-language	<p>English, Czech, German, Spanish, French, Arabic, Hebrew, Italian, Russian, Netherlands, Japanese, Polish, Chinese Simple, Chinese Tradition, Korean, Portuguese, Slovakian, Serbian, Swedish and Turkish.</p>
Upgrade/Provisioning	<p>Firmware upgrade via FTP/FTPS/HTTP/HTTPS.</p>
Association	<p>Up to 5 stations in star.</p> <p>Automatic or manual association to base station.</p>
Power & Green Energy Efficiency	<ul style="list-style-type: none"> ◦ Universal Power Supply: Input AC 100-240V 50/60Hz, Output 5VDC 1A, Micro-USB connection. ◦ PoE: IEEE802.3af Class 1, 0.44W–3.84W.
Package Content	<p>DECT Repeater Unit, Universal Power Supply, Ethernet cable, Quick Installation Guide, GPL statement</p>
Dimensions	<p>28.5 mm (H) x 130 mm (W) x 90 mm (D).</p>
Weight	<p>DECT Repeater unit: 143g; Universal Power Supply: 50g; Package: 360g.</p>

Temperature and Humidity	Operation: -10° to 50°C (14° to 122°F); Storage: -20° to 60°C (-4° to 140°F). Humidity: 10% to 90% non-condensing.
Compliance	FCC: Part 15D, Part 15B, MPE CE: EN60950, EN301489-1-6, EN301406, EN50385 RCM: AS/NZS60950 ANATEL: #2288-16-9452

Table 2: DP760 Technical Specifications

GETTING STARTED

This chapter provides basic installation instructions including the list of the packaging contents and description of the LED patterns.

Equipment Packaging

DP760
<ul style="list-style-type: none">1 DECT Unit.1 Universal power supply 5V.1 Ethernet cable.1 Quick Installation Guide.1 GPL Statement.

Table 3: Equipment Packaging




Figure 1: DP760 Package Content

Note

Check the package before installation. If you find anything missing, contact your system administrator.

Connecting DP760

To set up the DP760 DECT Repeater, please follow the steps below:




Figure 2: DP760 Back View

There are two options to connect DP760 DECT Repeater, either with the AC power or Power over Ethernet (PoE)

Connecting via AC power

1. Connect the micro-USB connector into the related port on the repeater station and connect the other end of the power adapter into an electrical power outlet.
2. Connect the supplied Ethernet cable between the Internet port on the DP760 DECT Repeater and the Internet port in your network or the switch/hub device port.




Figure 3: Connecting the Repeater Station

Connecting via PoE

To connect the DP760 DECT Repeater using PoE, you need to connect the Ethernet cable provided (or 3rd party network cable) between the Network Socket on the repeater station to Ethernet port of your PoE switch/hub.

DP760 Implementation Architecture

The DP750 Base Station can support up to 5 DP760 DECT Repeater stations to extend the coverage area of the base in all directions, including through floors and ceilings using star architecture as displayed on the following diagrams.

When a repeater powers on, it searches for signals from the base and any other repeaters registered to the same base. The repeater will automatically connect to the first available signal.

The base can hand-off calls to the repeaters as the user moves from one coverage area to another. When connected to the repeater, the DP720 handsets operate as it is connected to the base, and the hand-off from the base to the repeater can be completely invisible to the end user, even during an active call.

Note

DP760 can relay up to 2 concurrent calls.




Figure 4: Star Mode Configuration




in star mode configuration, the coverage area of the repeaters should overlap the coverage area of the base station.

DP760 LED Patterns

The DP760 has 5 LED lights. Please refer to following table describing the status of each LED.



Figure 5: DP760 LED Patterns

LED	Status
	Indicates Power ON/OFF.
	Indicates access to the network. <ul style="list-style-type: none"> ◦ Solid ON: When there is access to the network. ◦ Blinking: If there is no access to the network.
	Indicates status of the association between DP760 and DP750 <ul style="list-style-type: none"> ◦ Blinking: When the DECT station is scanning for available RFPs. ◦ Solid ON: When the association between DECT repeater and Base station is operational.



	<p>Indicates status of the association between DP760 and DP750 during calls.</p> <ul style="list-style-type: none"> ◦ Solid ON: When there are no active calls and the association between DECT repeater and Base station is operational. ◦ Blinking: During active calls.
	<p>Indicates status of the association link between the DP760 and DP750.</p> <ul style="list-style-type: none"> ◦ Solid ON: When the association between DECT and Base station is operational, and link is excellent. ◦ Blinking: <ul style="list-style-type: none"> ◦ Long ON, 1x short OFF if the association link is good. ◦ Long ON, 2x short OFF if the association link is weak. ◦ Long ON, 3x short OFF if the association link is poor

Table 3: Equipment Packaging

CONFIGURATION GUIDE

The DP760 can be configured via the Web GUI embedded using a Web browser. By default, DP760 is configured to obtain IP address from DHCP server where the unit is located and can be discovered using UPnP feature (by default enabled).

Configuration via Web Browser

The DP760 embedded Web server responds to HTTP/HTTPS GET/POST requests. Embedded HTML pages allow a user to configure the DP760 through a Web browser such as Google Chrome, Mozilla Firefox and Microsoft Internet Explorer.

Note: If DP760 has a known IP, users can access to its Web GUI by entering the IP address in their Web browser on a device connected to same network.

Accessing the Web GUI using UPnP Feature

DP760 supports UPnP feature (by default enabled) for auto discovery by computers in same network. Please refer to following steps to access DP760 Web GUI:

1. Power on DP760 and connect it to the network.
2. Connect a computer to same network as DP760. (The computer must be connected to the same sub-network as the DP760. This can be easily done by connecting the computer to the same hub or switch as the DP760).
3. Access **Network** directory on the computer.
4. Locate **DP760 – <MAC Address>** device and double click on it to access Web GUI.




Figure 6: DP760 UPnP Discovery

5. Enter admin’s username and password and press Login button to access the configuration menu. (Starting HW version 1.3A the default admin username is ‘admin’ while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin)

Accessing the Web GUI using DP750 Repeater Management Mode

The repeater management mode on the DP750 allows managing discovered / paired repeater stations and accessing the DP760 Web GUI from DP750 Web GUI. Please refer to following steps to access DP760 Web GUI using DP750 repeater management mode:

1. Access the Web GUI of your DP750 using the admin’s username and password. (Starting HW version 1.7A the default admin username is ‘admin’ while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **DECT → General Settings** and set **Enable Repeater Management** to *Yes*.
3. Press **Save and Apply** button, then reboot the unit to apply the new settings.
4. After finishing the reboot, access again the DP750 Web GUI.
5. Navigate to **Status → DECT Repeater Status**.
6. Access the discovered or paired repeater Web GUI by clicking on its IP address.
7. You will be redirected to login page of the repeater, enter admin’s username and password and press **Login** button to access the configuration menu.

Saving the Configuration Changes

After users make changes to the configuration, pressing the **Save** button will save but not apply the changes until the **Apply** button on the top of Web GUI page is pressed. Users can instead directly press the **Save and Apply** button. We recommend rebooting or powering cycle the device after applying all changes.

Web GUI Access Level Management

There are two default passwords for the login page:

User Level	Username	Password	Web Pages Allowed
End User Level	user	123	Status, Network Settings and Maintenance pages
Administrator Level	admin	The random password that can be found on the sticker at the back of the unit starting from HW version 1.3A. For lower hardware versions, the admin password is ‘admin’.	All pages

Table 3: Equipment Packaging

The password is case sensitive with a maximum length of 25 characters.

Note

When accessing the Web GUI with normal user level, **Advanced Settings** page will be hidden.

When changing any settings, always **SUBMIT** them by pressing the **Save** or **Save and Apply** button on the bottom of the page. If using the **Save** button, after making all the changes, click on the **Apply** button on top of the page to submit. After submitting the changes in all the Web GUI pages, reboot DP760 to have the changes take effect if necessary; most of the options under the **Maintenance** page require a reboot.

Changing User Level Password

1. Access the Web GUI of your DP760 using the admin’s username and password. (Starting HW version 1.3A the default admin username is ‘admin’ while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Press **Login** to access your settings.
3. Go to **Maintenance → Web/SSH Access**.
4. In **Web/SSH Access** page, locate **User Password** section:

1. Type in your new user password in **New Password** field.
2. Type in again same entered password in **Confirm Password** field.
5. Press **Save and Apply** to save your new setting.

Maintenance

- Firmware Upgrade
- Provisioning
- Web/SSH Access**
- TR-069
- Security Settings
- Date and Time
- Syslog
- Packet Capture
- Factory Reset
- Support

Web/SSH Access

User Password

New Password

Confirm Password

Admin Password

New Password

Confirm Password

Access Control Lists

White list for WAN side

Black list for WAN side

Figure 7: User Level Password

Note

DO NOT USE same password for both user and admin accounts.

Changing Admin Level Password

1. Access your DP760 DECT Repeater Web GUI by entering its IP address in your favorite browser.
2. Enter your admin's username and password. (Starting HW version 1.3A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin)
3. Press **Login** to access your settings.
4. Go to **Maintenance → Web/SSH Access**.
5. In **Web/SSH Access** page, locate **Admin Password** section:
 1. Type in your new Admin Password in **New Password** field.
 2. Type in again same entered password in **Confirm Password** field.
6. Press **Save and Apply** to save your new setting.

Maintenance

- Firmware Upgrade
- Provisioning
- Web/SSH Access**
- TR-069
- Security Settings
- Date and Time
- Syslog
- Packet Capture
- Factory Reset
- Support

Web/SSH Access

User Password

New Password

Confirm Password

Admin Password

New Password

Confirm Password

Access Control Lists

White list for WAN side

Black list for WAN side

Figure 8: Admin Level Password

Note

DO NOT USE same password for both user and admin accounts.

Changing HTTP/HTTPS Web Access Port

1. Access your DP760 DECT Repeater Web GUI by entering its IP address in your favorite browser.
2. Enter your admin's username and password. (Starting HW version 1.3A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
3. Press **Login** to access your settings.
4. Go to **Maintenance → Web/SSH Settings**.
5. In **Web/SSH Settings** page, locate **HTTP / HTTPS Web Port** field and change it to your new HTTP/HTTPS port.

Note

By default, the HTTP port is 80 and HTTPS port is 443.

6. Select the **Web Access Mode** depending on desired protocol (HTTP or HTTPS).
7. Press **Save and Apply** to save your new setting.

Note

A reboot is required for this change to take effect.

Maintenance

Firmware Upgrade

Provisioning

Web/SSH Access

Web/SSH Settings

Date and Time

Syslog

Packet Capture

Factory Reset

Support

Support Documentation

Debug Tools

Web/SSH Settings

HTTP Web Port

80

HTTPS Web Port

443

Web Access Mode

☐ HTTPS
☒ HTTP

Disable SSH

☒ No
☐ Yes

SSH Port

22

Save

Save and Apply

Reset

Figure 9: Web Access Port

Web Configuration Definitions

This section describes DP760 options available in its Web GUI. As mentioned, you can log in as an administrator or an end user.

- **Status:** Display the system info, network status, DECT status options.
- **DECT:** Configure DECT general settings, repeater name and RFPI manual configuration.
- **Network Settings:** Configure network basic and advanced settings.
- **Maintenance:** Configure upgrading and provisioning, Web/SSH access, date and time, and syslog, packet capture and factory reset settings.

Status Page Definitions

DECT Repeater Status		
Repeater Name	Displays name of DECT repeater. Default is DP760_[last 6 digit of MAC address].	
Repeater DECT RF Region	Indicates region of repeater station. Example: EU, US, Auto...	
Repeater Status	Status	Scanning for available RFPs: DP760 is scanning and searching for available RFPs (Radio Fixed Part Identity) address.
		Repeater is searching for the requested RFP: DP760 DECT repeater is searching for DP750 base station configured RFPI. (During manual association)
		Repeater is in normal operation: DP760 DECT repeater is operational and associated with the DP750. Note: The message "Repeater is operational after auto configuration procedure first time" appears briefly during DP760/DP750 association.
	Signal Strength	Displays the signal strength of the DECT repeater.
	Number of Active Calls	Displays number of active calls on the DECT repeater.

Global Functions	<ul style="list-style-type: none"> ● Base Station RFPI Address: Displays the RFPI address of the associated base station ● Disconnect: Disconnect the DP760 DECT Repeater from the DP750 Base Station.
Network Status	
MAC Address	Shows Device ID in hexadecimal format. This is needed by network administrators for troubleshooting. The MAC address will be used for provisioning and can be found on the label on original box and on the label located on the bottom panel of the device.
IP Address Mode	Indicates used IP address mode: DHCP, Static IP or PPPoE.
IP Address	Displays assigned IP address. Example: 192.168.5.110
Subnet Mask	Displays assigned subnet mask. Example: 255.255.255.0
Gateway	Displays assigned default gateway. Example: 192.168.5.1
PPPoE Link Up	Indicates PPPoE connection status.
DNS Server 1	Shows assigned DNS server address 1. Example: 8.8.8.8
DNS Server 2	Shows assigned DNS server address 2. Example: 8.8.4.4
System Info	
Product Model	Displays product model info. Default is DP760 .
Part Number	Shows product part number. Example: 9610003814A (last 2 digits show HW version, in this example 14A for HW version 1.4A).
Software Version	<ul style="list-style-type: none"> ● Firmware Status: Displays the status of the firmware loaded. ● Check for new firmware: Check configured server for most recent firmware version and compare to current version. After pressing button, you must reload or refresh this page to display status and check firmware availability. ● Boot: Specifies Boot version. ● Core: Specifies Core version ● Base: Specifies Base version ● Prog: Specifies Prog version. This is the main firmware release number, which is always used for identifying the software system of the DP760 ● Locale: Specifies Locale version ● Recovery: Specifies Recovery version
System Up Time	Indicates system uptime since last reboot.
System Time	Shows actual time and date according to your configuration.
Service Status	Reveals status of VoIP applications.
Core Dump	Provides generated core dump file when available if unit malfunctions.

Table 6: Status Pages Definitions

DECT Page Definitions

General Settings	
Repeater Name	Configures the name of the repeater station. Default is DP760_[last 6 digit of MAC address] .
Manually Configured Base RFPI	Configures manually RFPI of DP750 base station to connect to. If empty, the repeater station DP760 will search for DP750 base stations and connect automatically to the first one found.
Use Manually Configured RFPI	Allows to use manually configured RFPI (if non-empty) when set to Yes. If set to NO, the DP760 will search for a DP750 to connect with, regardless of manual configuration.

Table 7: DECT Page Definitions

Network Settings

Network Settings – Basic Settings		
IP Address Mode	Selects IP address mode (DHCP, Static IP or PPPoE) for DP760 DECT Repeater.	
Preferred DNS Server	Specifies preferred DNS server to use when DHCP, PPPoE or Static mode is set.	
DHCP Settings	Host name (Option 12)	Specifies the name of the client. The name may or may not be qualified with the local domain name. This field is optional but may be required by ISP.
	Vendor Class ID (Option 60)	Exchanges vendor class ID by clients and servers to convey particular configuration or other identification information about a client. Default is DP7XX.
PPPoE Settings	Configures PPPoE account ID, password and service name.	
Static IP Settings	Sets IP address, subnet mask, gateway, DNS server 1, and DNS server 2.	
Network Settings – Advanced Settings		
802.1X Mode	Enables 802.1X mode. To enable this mode, you should select EAP-MD5. Default is Disable .	
802.1X Identity	Configures the identity for 802.1X mode.	
MD5 Password	Determines the MD5 password for 802.1X mode.	
802.1X CA Certificate	Uploads / deletes the 802.1X CA certificates.	
802.1X Client Certificate	Uploads / Deletes the 802.1X Client Certificates.	
Enable LLDP	Activates LLDP (Link Layer Discovery Protocol). Default is Yes .	
Layer 2 QoS Settings	Enable VLAN	Enables / Disables the VLAN mode. Default is Disabled .

	Layer 2 QoS 802.1Q/VLAN Tag	Sets layer 2 QoS 802.1Q/VLAN tag. Default is 0.
	Layer 2 QoS 802.1p Priority Value for SIP signaling	Sets layer 2 QoS 802.1p priority value for SIP signaling. Default is 0.
	Layer 2 QoS 802.1p Priority Value for RTP media	Sets layer 2 QoS 802.1p priority value for RTP media. Default is 0.
UPnP Discovery Settings	Enable UPnP discovery	Enables UPnP discovery feature. Default is Yes .
	UPnP discovery notify interval	Specifies in seconds the interval to send out SSDP notifies. Default is 30 .

Table 8: Network Settings Pages Definitions

Maintenance Page Definitions

Firmware Upgrade	
Firmware Upgrade	Selects how firmware upgrade request will be sent: “Always Check for New Firmware”, “Check New Firmware only when F/W pre/suffix changes”, or “Always Skip the Firmware Check”.
HTTP/HTTPS Username	Enters user name to authenticate with HTTP/HTTPS server.
HTTP/HTTPS Password	Enters password to authenticate with HTTP/HTTPS server.
Always send HTTP Basic Authentication Information	Includes configured user name and password in HTTP request before receiving authentication challenge from the server. Default is No .
Verify host when using HTTPS	Verifies host name in server certificate when using HTTPS. Default is Yes .
Upgrade via	Selects firmware upgrade method: FTP/FTPS or HTTP/HTTPS.
Firmware Server Path	Sets IP address or domain name of firmware server. The URL of the server that hosts the firmware release. Default is fm.grandstream.com/gs .
Firmware File Prefix	Checks if firmware file is with matching prefix before downloading it. This field enables user to store different versions of firmware files in one directory on the firmware server.
Firmware File Postfix	Checks if firmware file is with matching postfix before downloading it. This field enables user to store different versions of firmware files in one directory on the firmware server.
Allow DHCP Option 43 and Option 66 to Override Server	Obtains configuration and upgrade server's information from DHCP server using options 66 and 43. Note: If DHCP Option 66 is enabled, the base will attempt downloading the firmware file from the server URL provided by DHCP, even though Firmware Server Path is left blank.
Automatic Upgrade	<p>Specifies when the firmware upgrade process will be initiated; there are 4 options:</p> <ul style="list-style-type: none">● Yes, check for upgrade at random every X days: User needs to specify a period in days.● No: Base station will only do upgrade once at boot up.● Check every X minutes: User needs to specify a period in minutes.● Check every day: User needs to specify “Hour of the day (0-23)”.● Check every week: User needs to specify “Hour of the day (0-23)” and “Day of the week (0-6)”. Note: Day of week is starting from Sunday. <p>Default is No.</p>

Firmware Key	Decrypts the firmware file using specified key (32-digit in Hexadecimal) when encrypted.
Provisioning	
XML Config File Password	Decrypts XML configuration file when encrypted. The password used for encrypting the XML configuration file is using OpenSSL.
HTTP/HTTPS Username	Enters user name to authenticate with HTTP/HTTPS server.
HTTP/HTTPS Password	Enters password to authenticate with HTTP/HTTPS server.
Always send HTTP Basic Authentication Information	Includes configured user name and password in HTTP request before receiving authentication challenge from the server. Default is No.
Verify host when using HTTPS	Verifies host name in server certificate when using HTTPS. Default is Yes.
Provisioning via	Choose the method that the base station uses to request handset ipei config file. Can use TFTP, HTTP,FTP,FTPS or HTTPS.
Config Server Path	Sets IP address or domain name of configuration server. The server hosts a copy of the configuration file to be installed on the DP750. Default is fm.grandstream.com/gs Note: Make sure to not prepend address with "http://" or any other protocol.
Config File Prefix	Checks if configuration files are with matching prefix before downloading them. This field enables user to store different configuration files in one directory on the provisioning server.
Config File Postfix	Checks if configuration files are with matching postfix before downloading them. This field enables user to store different configuration files in one directory on the provisioning server.
Allow DHCP Option 43 and Option 66 to Override Server	Obtains configuration and upgrade server's information from DHCP server using options 66 and 43. Note: If DHCP Option 66 is enabled, the DP750 will attempt downloading the firmware file from the server URL provided by DHCP, even though Config Server Path is left blank.
Automatic Provisioning	Specifies when provisioning process will be initiated; there are 4 options: <ul style="list-style-type: none"> ● No: Base station will only request configuration files once at boot up. ● Check every X minutes: User needs to specify a period in minutes. ● Check every day: User needs to specify "Hour of the day (0-23)". ● Check every week: User needs to specify "Hour of the day (0-23)" and "Day of the week (0-6)". Note: Day of week is starting from Sunday. Default is No .
Authenticate Conf File	Authenticates configuration file before being accepted. This protects the device configuration from unauthorized modifications. Default is No .
Upload Device Config	Uploads manually device configuration (XML and TXT formats are supported) to base station.
Device Config (TXT)	Downloads actual device configuration file in .txt format.
Device Config (XML)	Downloads default device configuration file in .xml format.
Backup Configuration	Generates an XML config file storing all current configuration after pressing Backup Settings and display list of backup files available (users need to wait a few seconds and refresh the provisioning page to display the backup files). Maximum of 10 backup files are supported and when it reaches 10 entries, this feature will be disabled.

	Note: Click on Download to download the specific backup or Delete to remove all the backup files.	
Web/SSH Access		
User Password	Configures user level password. Case sensitive and max. length of 30 characters.	
Confirm Password	Configures the new user password again to confirm the new password.	
Admin Password	Configures admin level password. Case sensitive and max length is 30 characters.	
Confirm Password	Configures the new user password again to confirm the new password.	
Access Control Lists	White list for WAN side	If white list exists, then only these IP addresses are allowed to web and SSH access.
	Black list for WAN side	If black list exists and white list is empty, then only these IP addresses are not allowed to web and SSH access
Web/SSH Settings		
HTTP Web Port	Customizes HTTP port used to access repeater Web GUI. Default is 80.	
HTTPS Web Port	Customizes HTTPS port used to access repeater Web GUI. Default is 443.	
Web Access Mode	Determines the protocol to be used for the Web GUI access. Default is HTTP.	
Disable SSH	Disables SSH access. Default is No.	
SSH Port	Customizes SSH access port. Default is 22.	
Date and Time		
NTP Server	Defines URL or IP address of the NTP (Network Time Protocol) server. Used by the repeater to synchronize the date and time. A list of public NTP servers can be found at http://www.ntp.org	
NTP Update Interval	Contacts NTP server at specified period of time (in minutes) to obtain the date and time. Default is 60 minutes.	
Allow DHCP Option 42 to NTP Server	Obtains NTP server address from a DHCP server using DHCP Option 42; it will override configured NTP Server. If set to No, the repeater will use configured NTP server to synchronize time and date even if a NTP server is provided by DHCP server. Default is Yes.	
Time Zone	Selects time zone to define date/time on the repeater station.	
Self-Defined Time Zone	Allows users to define their own time zone.	
Allow DHCP Option 2 to override time zone	Obtains time zone setting (offset) from a DHCP server using DHCP Option 2; it will override selected time zone. If set to No, DP760 DECT repeater will use selected time zone even if provided by DHCP server. Default is Yes.	
Syslog		
Syslog Server	Sets IP address or URL of system log server. The server collects system log information from the repeater station.	

Syslog Level	<p>Selects log level; the level is one of DEBUG, INFO, WARNING, ERROR (default is NONE). Syslog messages are sent based on the following events:</p> <div><div></div><div>1. product model/version on boot up (INFO level)</div><div>2. NAT related info (INFO level)</div><div>3. sent or received SIP message (DEBUG level)</div><div>4. SIP message summary (INFO level)</div><div>5. inbound and outbound calls (INFO level)</div><div>6. registration status change (INFO level)</div><div>7. negotiated codec (INFO level)</div><div>8. Ethernet link up (INFO level)</div><div>9. SLIC chip exception (WARNING and ERROR levels)</div><div>10. memory exception (ERROR level)</div></div> <p>Syslog uses USER facility. In addition to standard Syslog payload, it contains the following components: GS_LOG: [device MAC address] [error code] error message.</p> <p>Example: May 19 02:40:38 192.168.1.14 GS_LOG:[00:0b:82:00:a1:be][000] Ethernet link is up</p>	
Packet Capture		
Status	Displays packet capture status. When user starts to capture trace file, it will show “RUNNING” status, otherwise, it will show “STOPPED”.	
Factory Reset		
Force Reboot	Kills active processes and forces the reboot of DP750 base station.	
Configure Web UI Button	Reset Type	<p>Specifies the type of reset to perform via the Web UI reset button:</p> <p>- There are 3 reset type for Web UI button:</p> <div><div></div><div>● Full Factory Reset: Reset all the settings.</div><div>● NVRAM Settings Only: Reset all the settings except subscription information, so the handset will stay in subscribed after reset, but all the other settings like account info, call settings, audio settings, etc., will be reset.</div><div>● DECT Settings Only: Reset only the subscription (wipe out all the subscription information), but keep all the other settings like account, SIP settings.</div></div>
	Perform Selected Reset	Press Reset button to reset settings based on the reset type selected.
Configure Hardware Button	Reset Type	<p>Specifies the type of reset to perform via hardware button:</p> <p>- There are 4 reset types for hardware button:</p> <div><div></div><div>● Full Factory Reset: Reset all the settings.</div><div>● NVRAM Settings Only: Reset all the settings except subscription information, so the handset will stay in subscribed after reset, but all the other settings like account info, call settings, audio settings, etc., will be reset.</div></div>

		<ul style="list-style-type: none">● DECT Settings Only: Reset only the subscription (wipe out all the subscription information), but keep all the other settings like account, SIP settings.● Disabled: Disable the hardware button to factory reset the base for security purpose.
Support		
Support Documentation Offline Support	Online Support	Redirects users to tools page and DP7xx product pages available on Grandstream official website.
	Offline Support	Allows users to download MD Hole Location for wall mount.
Debug Tool	Remote Log Submission - Terms & Conditions	By clicking the submit button, you agree to allow the device to send these files to Grandstream to be used for troubleshooting purposes. If possible, please include a comment with information regarding the use of the device when the problem occurred. As an alternative to the device submitting the files, you may download the files below and submit them to Grandstream manually.
	Debug Log Files	Kills device control process on DECT repeater and generates core file and other debug information. Reboot required to restart process.

Table 9: Maintenance Pages Definitions

Rebooting from Remote Location

Press the **Reboot** button on the top right corner of the Web GUI page to reboot the DP760 remotely. The Web browser will then display a reboot message to confirm the reboot by pressing **OK** or avoid by clicking on **Cancel** button. Wait for about 1 minute to log in again.

DP760 DECT REPEATER ASSOCIATION WITH DP750

After factory reset, DP760 will be set to “Auto-region” mode. In this mode, the three LEDs of right side keep quick blinking, then the DP760 will search the base signal in the current environment to auto associate with it and then auto switch to the same region (EU, US or BR) of the base station.

Enabling Repeater Mode on DP750

Before associating the DP760 DECT Repeater to your DP750 Base Station, you should firstly enable the repeater mode on your base station. Please refer following steps to enable the repeater mode on the DP750 base station:

1. Access the Web GUI of your DP750 using the admin’s username and password. (Starting HW version 1.7A the default admin username is ‘admin’ while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **DECT → General Settings** and set **Enable Repeater Mode** to **Yes**.

The screenshot shows the 'General Settings' page for a DECT system. On the left, there is a sidebar with navigation links: 'General Settings' (selected), 'SIP Account Settings', 'Handset Line Settings', and 'Handset Settings'. The main content area is titled 'General Settings' and contains several configuration fields: 'Base Station Name' (set to 'DP750_870884'), 'Admin PIN Code' (empty), 'Enable Repeater Mode' (radio buttons for 'No' and 'Yes', with 'Yes' selected and highlighted by a red box), 'Enable Repeater Management' (radio buttons for 'No' and 'Yes', with 'Yes' selected), and 'Clear Call Logs' (a 'Delete' button).

Figure 10: Enable Repeater Mode

3. Press **Save and Apply**, then **Reboot** the base to apply the new settings.

DP760 DECT Repeater Association

After enabling the repeater mode on DP750 Base Station, you can easily associate it with your DP760 DECT Repeater using one of the following methods:


- **Auto Association**
- **Manual Association**
- **Use DP750 Repeater Management to associate DP760**

Note

Using auto/manual association methods, the DP760 repeater will not be listed on DP750 "DECT Repeater Status" page even if "Repeater Management Mode" is enabled on DP750.

Auto Association


To auto associate your DP760 DECT Repeater with DP750 Base Station:

1. Please put the DP760 DECT Repeater close to DP750, then power on the DP760.
2. After the DP760 finish booting, the association LED  will be blinking to indicate that the repeater is searching for nearby base stations.

Note

If all the LEDs remain on, it indicates that the DP760 Repeater has successfully associated with a DP750 Base and ready for use. You may need to dissociate it before continuing (Please refer to [DP760 DECT REPEATER DISSOCIATION]).

3. Open subscription on your DP750 Base Station using one of following methods:

- Rebooting the Base station.
- Long press on page/subscribe button on the back panel of DP750 for 7 seconds.
- Access DP750 Web GUI and press subscribe button .

4. The DP760 DECT Repeater will automatically pair to DP750. Upon successful association with the DP750 Base station all LEDs will turn ON and the repeater status will be updated as following.

Status

DECT Repeater Status

Network Status

System Info

Repeater Name

DP760_9e274c

Repeater FW Version

FW 03.00 Build 1294

Repeater DECT RF Region

EU

Repeater Status

Status

Repeater is in normal operation

Signal Strength

Link is excellent

Number of Active Calls

0

Global Functions

Base Station RFPI Address

02C344DDA0 (RPN 2)

Base Station IP Address

192.168.5.141

Disconnect from Base Station

Disconnect

Figure 11: Repeater Status – Associated (Auto Association)

Note

- For auto association, the option **Use manually configured RFPI** under DP760 Web GUI should be disabled (by default disabled).
- The association may take up to a few minutes. Time will vary depending on the number of DP760.

Manual Association

To manually associate your DP760 DECT Repeater to your DP750 Base Station:

- Access the Web GUI of your DP760 using the admin's username and password. (Starting HW version 1.3A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin). Refer to **[Accessing the Web GUI]**
- Navigate to **DECT → General Settings** and set **Use Manually Configured RFPI** to **Yes**.
- On **Manually Configured Base RFPI** field, configure your DP750 Base Station RFPI address.

Note

The RFPI Address of your DP750 Base Station is available under the Web GUI → **Status → DECT Status → Base DECT RFPI Address**.

- Click **Save and Apply** to confirm the new settings.
- Go to DECT Repeater Status page and click on "Manual-Lock to xxxxxxxxxx".
- The DP760 DECT Repeater will automatically pair to DP750. If the association is correctly associated, all the LEDs will remain solid on and the repeater status will be updated as following.

Status

DECT Repeater Status

Network Status

System Info

Repeater Name

DP760_9e274c

Repeater FW Version

FW 03.00 Build 1294

Repeater DECT RF Region

EU

Repeater Status

Status

Repeater is in normal operation

Signal Strength

Link is excellent

Number of Active Calls

0

Global Functions

Base Station RFPI Address

02C344DDA0 (RPN 2)

Base Station IP Address

192.168.5.141

Disconnect from Base Station

Disconnect

Figure 12: Repeater Status – Associated (Manual Association)

Note

Make sure that **Repeater Mode** is enabled on your DP750 Base Station.

Use DP750 Repeater Management to Associate DP760

The repeater management mode on the DP750 allows to associate, dissociate and manage discovered and paired repeater stations from DP750 web GUI.

Enabling Repeater Management Mode

The following steps illustrate how to enable and use the Repeater Management mode on DP750:

1. Access the Web GUI of your DP750 using the admin's username and password. (Starting HW version 1.7A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **DECT → General Settings** and set **Enable Repeater Management** to **Yes**.
3. Press **Save and Apply**, then reboot the unit to apply the new settings.

DECT

General Settings

General Settings

SIP Account Settings

Handset Line Settings

Handset Settings

HS1 Settings

HS2 Settings

HS3 Settings

HS4 Settings

HS5 Settings

Base Station Name

DP750_870884

Admin PIN Code

Enable Repeater Mode

☐ No
☒ Yes

Enable Repeater Management

☐ No
☒ Yes

Clear Call Logs

Delete

Handset Settings

Handset	Handset Name	Handset Phonebook	Offhook Auto-dial
HS1	HS1	PB1	
HS2	HS2	PB2	
HS3	HS3	PB3	
HS4	HS4	PB4	
HS5	HS5	PB5	

Save

Save and Apply

Reset

Figure 13: Repeater Associated Status

Associating DP760 using Repeater Management Mode on DP750

The repeater management mode displays discovered and paired devices using their name, IP and Mac addresses and also gives the possibility of associating the DP750 Base Station with DP760 DECT Repeater.

Please refer to following steps in order to associate DP760 with DP750 using repeater management mode.

1. Access the Web GUI of your DP750 using the admin's username and password. (Starting HW version 1.7A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **Status → DECT Repeater Status** and select the repeater station from **Discovered Devices**.
3. Click **Link** button to associate the base and repeater stations.

Note

The DP760 Repeater stations associated with DP750 Base Station are displayed and available under **Status → DECT Repeater Status → Paired Devices** with their status, signal strength, number of active calls and also the ability to disconnect them from the paired base station.

Status

Account Status

DECT Base Status

DECT Repeater Status

Line Options

Network Status

System Info

DECT Repeater Status

Paired Devices

Discovered Devices

Model	Name	IP	MAC	Link
DP760	DP760_8b556b	192.168.5.125	000b828b556b	Link

Figure 14: DECT Repeater Status on DP750

DP760 DECT REPEATER DISSOCIATION

To disconnect DP760 DECT Repeater from the Base Station DP750, please refer to following options:

Using DP760 Web GUI

To disconnect your DP760 DECT Repeater via Web GUI, please refer to following steps:

1. Access the Web GUI of your DP760 using the admin's username and password. (Starting HW version 1.3A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **Status → DECT Status → Global Functions** and press **Disconnect**.
3. The DP760 DECT Repeater will be automatically disconnected from the DP750 and it will start again scanning for available RFPs.




Figure 15: DECT Repeater Status on DP750

Using Page Button

Long press on page button on the back panel of DP760 for 7 seconds, it will remove the association values of the previous base station.

Using Repeater Management Mode on DP750

To disconnect your DP760 DECT Repeater using the repeater management mode on DP750:

1. Access the Web GUI of your DP750 using the admin's username and password. (Starting HW version 1.7A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **Status → DECT Repeater Status**.
3. Select the repeater station from **Discovered Devices**.
4. Click **Unlink** button to dissociate the repeater from the base station.




Figure 16: DECT Repeater Status on DP750

UPGRADING AND PROVISIONING

The DP760 DECT Repeater can be upgraded via FTP/FTPS/HTTP/HTTPS by configuring the URL/IP Address for the FTP/FTPS/HTTP/HTTPS server and selecting a download method. Configure a valid URL for FTP/FTPS/HTTP/HTTPS ; the server name can be FQDN or IP address.

Examples of valid URLs:

firmware.grandstream.com

fw.ipvideotalk.com/gs

Firmware Upgrade Procedure

Please follow below steps in order to upgrade the firmware version of your DP760 repeater station:

1. Access the Web GUI of your DP760 using the admin's username and password. (Starting HW version 1.3A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin).
2. Navigate to **Maintenance → Firmware Upgrade** page, enter the IP address or the FQDN for the upgrade server in **Firmware Server Path** field and choose to upgrade via FTP/FTPS/HTTP/HTTPS.
3. Make sure to select **Always Check for New Firmware**.
4. Update the change by clicking the **Save and Apply** button. Then reboot or power cycle the device to update the new firmware.

Maintenance

Firmware Upgrade

Provisioning

Web/SSH Access

TR-069

Security Settings

Date and Time

Syslog

Packet Capture

Factory Reset

Support

Firmware Upgrade

Base Firmware

Firmware Upgrade

☒ Always Check for New Firmware
☐ Check New Firmware Only When F/W pre/suffix Changes
☐ Always Skip the Firmware Check

HTTP/HTTPS/FTP/FTPS User Name

HTTP/HTTPS/FTP/FTPS Password

☒ No ☐ Yes

☐ No ☒ Yes

☒ HTTP ☐ HTTPS ☐ FTP ☐ FTPS

Firmware Server Path

fm.grandstream.com/gs

Firmware File Prefix

Firmware File Postfix

Allow DHCP Options 43, 66 and 160 to override Server

☐ No ☒ Yes

Automatic Upgrade

☒ No
☐ Yes, check for upgrade at random every

1

 day(s)
☐ Yes, check for upgrade every

10080

 minute(s)
☐ Yes, check for upgrade every day
☐ Yes, check for upgrade every week

Random Interval Start Time

1

 :

1

Random Interval Stop Time

1

 :

1

Hour of the Day(0-23)

1

Day of the Week (0-6)

1

Firmware Key

Upgrade

Start

Handset Firmware

Handset firmware

Upload

Delete

Automatic Upgrade

☐ No ☒ Yes

Save

Save and Apply

Reset

Upgrading via Local FTP/HTTP Servers

For users that would like to use remote upgrading without a local FTP/HTTP server, Grandstream offers a NAT-friendly HTTP server. This enables users to download the latest software upgrades for their devices via this server. Please refer to the webpage:

<http://www.grandstream.com/support/firmware>

Alternatively, users can download a free FTP or HTTP server and conduct a local firmware upgrade. A free windows version FTP server is available for download from:

<https://filezilla-project.org/download.php?type=server>

Instructions for local firmware upgrade via FTP:

1. Unzip the firmware files and put all of them in the root directory of the FTP server.
2. Connect the PC running the FTP server and the phone to the same LAN segment.
3. Start the FTP server and configure the FTP server in the phone's web configuration interface.
4. Configure the Firmware Server Path to the IP address of the PC.
5. Configure the Admin and password authentication Credentials set on your FTP server.
6. Save and apply the changes and reboot the base station.

End users can also choose to download a free HTTP server from <http://httpd.apache.org/> or use Microsoft IIS web server.

RESTORE FACTORY DEFAULT SETTINGS

Warning

Restoring the Factory Default Settings will delete all configuration information on the repeater. Please backup or print all the settings before you restore to the factory default settings. Grandstream is not responsible for restoring lost parameters and cannot connect your device to your VoIP service provider.

Resetting DP760 Repeater Station

There are two methods to reset your DP760 DECT Repeater to the default settings:

Via Reset Button

1. Locate the reset hole on the back panel of your DP760.
2. Insert a pin in this hole, and press for about 7 seconds.
3. Take out the pin. The unit will restart automatically with parameters restored to default values.

Note

A quick press on the reset hole will only reboot the unit.

Via Web GUI

1. Access your DP760 DECT Repeater Web GUI.
2. Enter your admin's username and password. (Starting HW version 1.3A the default admin username is 'admin' while the admin password is the random password that can be found on the sticker at the back of the unit. For lower hardware versions; the default username and password are: admin/admin)
3. Press **Login** to access and navigate to **Maintenance → Factory Reset**.

4. Press Reset button and the unit will prompt a confirmation message, press **OK** to reset the repeater, then the unit restart automatically with parameters restored to default values or press **Cancel** to annul the reset.

CHANGE LOG

This section documents significant changes from previous versions of the administration guide for DP760. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

Firmware Version 1.0.21.10

- No Major changes.

Firmware Version 1.0.21.6

- No Major changes.

Firmware Version 1.0.21.4

- No Major changes.

Firmware Version 1.0.21.2

- No Major changes.

Firmware Version 1.0.19.8

- No Major changes.

Firmware Version 1.0.19.6

- No Major changes.

Firmware Version 1.0.19.5

- No Major changes.

Firmware Version 1.0.19.4

- No Major changes.

Firmware Version 1.0.19.3

- No Major changes.

Firmware Version 1.0.19.2

- No Major changes.

Firmware Version 1.0.17.8

- No Major changes.

Firmware Version 1.0.17.4

- No major changes.

Firmware Version 1.0.17.1

- No major changes

Firmware Version 1.0.15.15

- No major changes

Firmware Version 1.0.15.6

- No major changes

Firmware Version 1.0.15.3

- No major changes

Firmware Version 1.0.15.2

- No major changes

Firmware Version 1.0.13.8

- No major changes.

Firmware Version 1.0.13.0

- No major changes.

Firmware Version 1.0.11.12

- No major changes.

Firmware Version 1.0.11.4

- No major changes.

Firmware Version 1.0.11.2

- No major changes.

rmware Version 1.0.9.9

- No major changes.

Firmware Version 1.0.9.1

- No major changes.

Firmware Version 1.0.7.5

- No major changes.

Firmware Version 1.0.4.10

- No major changes.

Firmware Version 1.0.4.7

- No major changes.

Firmware Version 1.0.4.2

- No major changes.

Firmware Version 1.0.3.40

- Added support for automatic upgrade and provisioning be triggered at a random time in every certain day. [Automatic Upgrade]

Firmware Version 1.0.3.34

- This is the initial version for DP760.

Need Support?

Can't find the answer you're looking for? Don't worry we're here to help!

[CONTACT SUPPORT](#)