



Grandstream Networks, Inc.

GWN Management

GWN App for Android – User Manual



WELCOME


Manage the network-based devices at any time from anywhere using Android device with the GWN app. This free app links seamlessly with devices registered in GWN.Cloud or GWN Manager, and allows users to conveniently monitor and manage the network established by GWN devices. The GWN app extends web features to smartphones to allow you to manage the network and be productive while on the go: monitor network/device/client status in different time periods, notify alert information once an alert event occurs, add the device to the network via phone camera scanning or manually fill in device MAC and its corresponding password, monitor device details including usage and other information, support debug tools for problem-tracking, configure your network as well as devices according to your needs, and much more. There is no purchase necessary to manage the network-based devices with the GWN app.

GETTING STARTED

Getting GWN App

GWN app is compatible with most Android devices running Android 5.0 or higher, including mobile phones, tablets, etc.

The app is available on [Google Play](#).



GWN App on the Google Play

Login to GWN App

When you open the GWN app, you will be greeted by a screen that has two options, one for GWN Cloud platform (GWN.Cloud), and one for GWN on-premise management platform (GWN Manager). Please refer to the screenshot below.



GWN App Main Screen

To use GWN app, users need to have an account previously created on a GWN Management Platform.


- Refer to this link to sign up for GWN.Cloud: <https://www.gwn.cloud/login>
- Refer to these links to install GWN Manager and create an account after that:

[GWN Manager – Quick Installation Guide](#)


[GWN Manager – Deploying a Virtual Machine from an OVA file](#)

Login screen tools


Even before log in, the user has some tools to use to either discover GWN devices on the same network or run a mobile speed test to evaluate the network performance and know how many GWN devices are discoverable on the network with very useful information like the GWN device IP/MAC addresses, device model, version number and type (master or slave). Please refer to the figures below:




Login screen tools – part 1



Login screen tools – part 2




Login screen tools – part 3




For more details about Speed Test, please [AP Details – Tools](#).

Once the GWN app is installed on your device, click on the app icon to start it, then click on GWN.Cloud or GWN Manager to log in.


- **GWN.Cloud:** enter the Email/Login Name and Password of the account previously created.
- **GWN Manager:** enter the server address (IP address), Email/Login Name and password.



GWN App Home Screen




GWN App Login Page – GWN.Cloud



GWN App Login Page – GWN Manager

For GWN.Cloud, on the top right corner, users could specify which zone to use:


1. Select the proper Zone World/EU Region for your GWN.Cloud Account



GWN App Login Page


About

The **About** page shows the version of the app installed on your mobile phone and if an upgrade is available.



About page


The user can also click on **"Model"** to see the latest firmware version for each device.



GWN devices latest firmware versions

Dashboard

The Dashboard page provides general information that can be used to monitor both networking devices and clients connected to them.




GWN App Dashboard tab

Internet Health

Network Health Monitor is a feature that monitor the WAN (WAN ports or Device group) and displays the WAN status for the last 12 hours for each WAN with color code: **Green** (Normal), **Red** (Abnormal) and **Grey** (Offline).


On the Dashboard screen under Internet Health, a graphical representation of the network health is displayed for the last 12 hours. Please refer to the figure below:



Dashboard – Internet Health

Bandwidth Usage and Clients Count

From the Bandwidth usage and Clients count interface, users can monitor their bandwidth as well as the number of clients connected per time. The time range for monitoring can be set to 1 Day, 1 Week, or 1 Month.




Bandwidth Usage and Clients Count

- Press the drop-down arrow on the top to choose your network
- Available information:
- Bandwidth Usage Upload/Download
- Clients Count
- Select to display information either in 1 day, 1 week, 1 month, 3 months or 6 months.

Top Devices, Clients, SSIDs, Websites

The top Devices, Clients, SSIDs, and Websites interface as the name suggests displays the top Devices, Clients, SSIDs, and Websites based on the data/Bandwidth usage.



Top Devices, Clients, SSIDs, and Websites

Devices

The Devices tab displays the list of devices paired with GWN platform for each Network/Model and allows users to add new GWN devices.

The following tables show the requirements of Grandstream networking products including GWN Access Points, GWN Routers, GWN Switches and GWN App versions (Android and iOS) for GWN Management Platforms (GWN.Cloud & GWN Manager):

o **GWN Access Points: minimum and recommended version**

Model	Minimum	Recommended
GWN7600	1.0.15.20	1.0.25.10
GWN7600LR	1.0.15.20	1.0.25.10
GWN7602	1.0.15.20	1.0.25.10
GWN7605	1.0.15.18	1.0.25.10
GWN7605LR	1.0.15.18	1.0.25.10
GWN7610	1.0.15.18	1.0.25.10
GWN7615	1.0.15.18	1.0.25.10
GWN7624	1.0.21.5	1.0.25.10
GWN7625	1.0.21.5	1.0.25.10
GWN7630	1.0.15.20	1.0.25.10
GWN7630LR	1.0.15.20	1.0.25.10
GWN7660	1.0.19.4	1.0.25.10
GWN7660LR	1.0.19.4	1.0.25.10
GWN7661	1.0.23.26	1.0.25.10
GWN7662	1.0.23.27	1.0.25.10
GWN7664	1.0.21.4	1.0.25.10
GWN7664LR	1.0.23.4	1.0.25.10

AP minimum and recommended version

o **GWN Routers: minimum and recommended version**

Model	Minimum	Recommended
GWN7001	1.0.1.6	1.0.3.5
GWN7002	1.0.1.6	1.0.3.5
GWN7003	1.0.1.6	1.0.3.5

GWN7052	1.0.5.34	1.0.7.2
GWN7052F	1.0.5.4	1.0.7.2
GWN7062	1.0.5.34	1.0.7.2

Router minimum and recommended version

○ **GWN Switches: minimum and recommended version**

Model	Minimum	Recommended
GWN7801	1.0.3.19	1.0.3.19
GWN7801P	1.0.3.19	1.0.3.19
GWN7802	1.0.3.19	1.0.3.19
GWN7802P	1.0.3.19	1.0.3.19
GWN7803	1.0.3.19	1.0.3.19
GWN7803P	1.0.3.19	1.0.3.19
GWN7806	1.0.1.14	1.0.1.14
GWN7806P	1.0.1.14	1.0.1.14
GWN7811	1.0.1.8	1.0.1.8
GWN7811P	1.0.1.8	1.0.1.8
GWN7812P	1.0.1.8	1.0.1.8
GWN7813	1.0.1.8	1.0.1.8
GWN7813P	1.0.1.8	1.0.1.8

Switch minimum and recommended version

○ **GWN App: minimum and recommended version**

Platform	Minimum	Recommended
iOS	1.0.5	1.3.14
Android	1.0.0.14	1.0.3.14

App minimum and recommended version

Adding New GWN Device

To add a device to GWN.Cloud, the administrator needs two pieces of information:

- o MAC address of the device.
- o Password printed on the device sticker.

Note:

GWN management platforms support adding more than one GWN router on the same network.


Adding a new device to your GWN.Cloud Account

There are 2 methods to add a GWN device to the cloud using GWN App:

- o **Method 1: Adding a new device manually**
- o **Method 2: Adding a new device by scanning Barcode**


Method 1: Adding a new device manually

1. Locate the MAC address on the MAC tag of the unit, which is on the device, or on the package.
2. Locate the Password.




GWN device MAC address and Password

3. From **the Devices** tab, click on **“Plus”** button and select **Manual Add**, then enter device information:



Manual Add Devices to GWN.Cloud Account – Part 1

Once, the GWN device information is filled in, please click on **“Done”** button.



Manual Add Devices to GWN.Cloud Account – Part 2

The following table describes the required parameters to add a new device to GWN.Cloud using GWN App.

Section	Description
Name	Enter a name for the new device to identify it easily.
MAC	Enter the MAC address of the new device.
Password	Enter the device Password.
Device Group	Select the device group from the list
Device Remarks	Enter a device remarks

Adding a new device manually

Method 2: Adding a new device by scanning Barcode


New devices can also be added to GWN.Cloud by Scanning the Barcode from the device sticker using a mobile phone camera.

1. From the **Devices** tab click on **"Plus"** button and select **Scan Add**, then point the mobile phone camera to the device's sticker.



Adding a new device by Scanning the Barcode

- Once added, the list of devices will be displayed on the **Devices** tab as shown below:




New device added to GWN.Cloud using GWN Application

Adopt a new device to your GWN Manager Account


The GWN Manager will automatically scan and detect the available devices on your Network.

1. From the **“Devices”** tab, click on **“Plus”** button.




Adopt a device to GWN Manager – part 1

2. The available GWN devices on the same network will be listed here, select the GWN device then click on **“Add”** button below.




Adopt a device to GWN Manager – Part 2

Then, a pop up dialog will be displayed to confirm that the GWN device has been added to the GWN Manager successfully.



Adopted successfully


The adopted devices can be found under the **"Devices"** tab.




Adopted Devices

Search/Filter GWN Devices

Select a network from the list and all the devices assigned to it will be displayed then you can filter based on the models or GWN devices status (Online, Offline). To search the devices please click on the search icon on the right side. Refer to the figures below.




Search Devices



Type the device name or MAC address

For each device, the application displays the number of clients connected as well as the data usage. Users can search devices by name or MAC address.

Click on  to sort GWN devices by the number of connected clients.



Sort devices

Device Details

Click on a device to view more details about it and monitor it in real-time. The Device details page contains 4 subsections


- Usage
- Info
- Tools
- Configuration

Note:

This page is dependent on the device, each GWN device (GWN APs, GWN Routers and GWN Switches) may show different info or has extra tools or requires different configuration.

Usage

The usage tab displays a graph for Bandwidth usage and client count monitoring for the selected device.



Usage Tab

Info

The info tab displays all the information related to the selected device including Model, Firmware Version, IP, MAC address, etc.

AP Details	
Usage Info Tools Configuration	
Basic	
Name	-
MAC	CD:74:AD:90:B2:40
Model	GWN7624
Firmware Version	1.0.25.10
IP	192.168.5.110
IPv6	-
Part Number	96400052108
Boot Version	0.0.0.1
Device Remarks	-
Uptime	3h 57m
System Time	2023-09-25 05:06PM
Load Average	1min: 2.63 5min: 2.61 15min: 2.63
CPU Temperature	41°C
Memory Usage	66 MB
Current Rate	↑ 3.65Kbps ↓ 1.2Kbps

Device Details – Info Tab – part 1

AP Details	
Usage Info Tools Configuration	
Memory Usage	66 MB
Current Rate	↑ 3.65Kbps ↓ 1.2Kbps
Link Speed	-
POE	1000 M/FD
LAN1	Disconnected
LAN2	Disconnected
LAN3	Disconnected
2.4G RF Information	
Channel	-
Wireless Power (dBm)	0
Clients Count	0
SSID	>
5G RF Information	
Channel	36
Wireless Power (dBm)	16
Clients Count	1 >
SSID	>

Device Details – Info Tab – part 2


Tools

The GWN app provides different tools to monitor and troubleshoot issues related to the selected devices from the app, users can locate the devices, clear usage, and run ping and traceroute tests and even run a speed test right from the app itself.

Note:


Speed Test feature is only supported on GWN Access Points except the model GWN7610 and GWN7602.

To run a speed test, please click on **“Speed Test icon”** as shown below:




Device details – Tools

The first speed test is testing download speed.




Speed Test – Download

Once, download speed test is over, the second test is testing upload speed.



Speed Test – Upload

Finally, the user will be able to see the final result, including Download/Upload speed and also the Ping response time in ms (Millisecond). To run the speed test again, click on **“Test Again”** button or to change the test server then click on **“Specify Test Server”** text.




Speed Test – Result

○ **Locate a device**

To locate the selected device, click on locate **“Location”** icon, the LED lights of the device will start blinking for 2 minutes, click on **Close** to end the location.

Note:

Locate a GWN device feature with LED lights is only supported on GWN Access points devices.



Locate Device

○ **Ping**


The ping tool is used to ping a remote device to test the connectivity. To ping another device from the GWN app, set the target to the IP address or domain of the remote device, then click on the Run button, the result will be displayed on a new page:



Ping results

○ **Traceroute**

Traceroute allows users to check the number of hops between the devices as well as all the gateways traversed to reach the destination.




Traceroute Test

For more details, please visit [GWN Management Platforms – User Guide \(Configure a device\)](#)


CLIENTS

The **Clients** tab allows monitoring wired or wireless clients as well as Guests that are connected using Captive Portal. This tab allows also to search for a specific client by its MAC or Hostname and sort clients by data usage. Please refer to the figure below:



Clients list and Search

Click on each client to view its bandwidth usage and info including the following: MAC address, IP, Client Status, SSID connected to, Channel, etc. Refer to the figures below:



Client Usage


The screenshot shows the 'Client Details' page with the 'Info' tab selected. The client information is as follows:

Hostname	android-ac7ebce922cad3f7
MAC	98:E7:9A: [REDACTED]
Client Status	Online
IP	192.168.80.112
IPv6	-
VLAN ID	1
Connection	Wireless
SSID	Labes
Frequency	2.4G
RSSI	-49
Station Mode	11NG_HT20
Channel	6
Guest	No
Usage	53.92MB 1.32MB 52.59MB
Current Rate	33bps 32bps
Associated Device	GWN7052F C0:74:AD: [REDACTED]

Client Details

Block Client


To block a client, navigate to The **Clients** tab, then either select the client from the list or search the client either by the MAC Address or Hostname, tab on the client then on the **Info** tab scroll down to the bottom of the page then toggle ON **Block**. Please refer to the figure below:




Block a client

Alerts


Alerts page displays alerts about the network, the user can specify to display only certain types like **(System, Performance, Security or Network)** or the levels **(Emergency, Warning or Notice)**. To check the alerts which have been generated, please navigate to **Alerts tab** page. Please refer to the figures below:



Alerts tab




Alerts – Levels




Alerts – Types

The alerts can be displayed either by type or levels. However, that is not the only way to display them. The user can filter through the alert log using a date interval or search by MAC address or device name.




Alerts – date interval



Alerts – Search

For more options, please click on the “...” three dots on the top right corner of the screen as shown in the figure below:

The user can mark all notifications as read, delete all or delete the selected ones.




Alerts – more options


Alert Settings

In this page the user can select the alerts to be displayed, four categories or alerts are available (**system, performance, security and network**) and each category has even more options. Please check the figures below:


- **System Alert** includes: GWN.Cloud/GWN Manager, GWN Routers, GWN Switches and GWN Access points.
- **Performance Alert** includes: GWN.Cloud/GWN Manager, GWN Routers, GWN Switches and GWN Access points.
- **Security Alert:** GWN Access points (Rogue AP).
- **Network Alert** includes: GWN Routers, GWN Switches, GWN Access points and Client.



Alerts Settings – System



Alerts Settings – Performance




Alerts Settings – Network


Alert Notification

In this screen, Emails addresses can be specified to receive notifications for the selected alerts, the notifications can be sent to the configured emails or pushed to the APP.

To enable APP push or email push, click on the respective icon as shown below:



Alert Notification screen




Alert Notification – Email

SETTINGS

The **Setting** tab allows users to check or configure: Wi-Fi, LAN, Internet, VPN, Firewall & Security, Profiles and System.


To access the **Settings** tab, click on the icon “**Settings**” as shown below:



Settings Tab

WiFi


In this section, the user can configure all the related Wireless settings including SSIDs, Radio Settings, and Mesh.




WiFi Settings

Wireless LAN

On this page, the user can Edit, Enable, Disable or even Add another Wireless LAN (SSID). Click on the previously created Wireless LAN to edit or click on **“Plus”** icon to add another Wireless LAN.



Wireless LAN list



Wireless LAN parameters

Please refer to the table below for the descriptions of the fields:

Basic	
Enabled	Enable wireless LAN
SSID	Specify the SSID name
Client IP Assignment	<ul style="list-style-type: none"> ● Bridge: IP addresses will be assigned without any translation. ● NAT: IP addresses will be assigned and translated between networks.
Associated VLAN	The VLAN ID associated with the wireless LAN.
Enable Captive Portal	Enable or disable captive portal. If it's enabled, select the captive portal policy.
SSID Band	Configure the wireless bands used for the transmissions. <ul style="list-style-type: none"> ● 2.4Ghz ● 5Ghz ● Dual Band: Enable both 2.4Ghz and 5Ghz.
Access Security	
Security Type	Configure the security type of your wireless network. <ul style="list-style-type: none"> ● Open ● Personal ● Enterprise ● PPSK with RADIUS ● PPSK without RADIUS ● Hotspot 2.0 OSEN


WPA Pre-Shared Key	Enter the WPA Pre-Shared key
WPA Mode	Select from the list: <ul style="list-style-type: none"> • WPA/WPA2 • WPA2 • WPA2/WPA3 • WPA3
WPA Encryption Type	Select the WPA encryption type, 2 options are available: <ul style="list-style-type: none"> • AES • AES/TKIP
802.11w	The 802.11w standard is used to prevent certain types of WLAN DoS attacks. 802.11w extends strong cryptographic protection and provides data integrity and replay protection for broadcast/multicast Robust management frames. Set this option to be either Disabled or Required . <ul style="list-style-type: none"> • Optional: both of the client supported and unsupported 802.11w may have the network access authority; • Required: only the client supported 802.11w have the network access authority.
Access Control	
MAC Filter	Enable filtering based on MAC address. Then select from blacklist or whitelist.
Client Isolation	Enable client isolation. If it's enabled, select from client isolation mode (Radio, Internet or Gateway).
Client Time Policy	Enable a client time policy. Note: Please note that GWN mobile application currently does not support configuring a client time policy. In order to set this feature, please use the web navigator to access to GWN platform or you can select from the previously created ones.
Bandwidth Control	Enable bandwidth control. <ul style="list-style-type: none"> • Per SSID • Per Client Note: Please note that GWN mobile application currently does not support configuring a bandwidth control policy. In order to set this feature, please use the web navigator to access to GWN platform.
Schedule	Schedule when the SSID would be functional. Note: Please note that GWN mobile application currently does not support configuring a schedule. In order to set this feature, please use the web navigator to access to GWN platform.
Device Management	
Method	Select the method of device selection either by devices or device group
Member Devices	The list of all the devices which are members of this specific SSID.
Advanced	
SSID Hidden	Enable or disable to hide the SSID.
DTIM Period	Set the DTIM period.
Wireless Client Limit	Set a limit for the number of clients which can connect to the wireless network.
Client Inactivity Timeout	Configure the period of inactivity of a client before being disconnected from the wireless network

(seconds)	
Client Bridge	Click to toggle ON or OFF client bridge feature
Multicast/Broadcast Suppression	<p>Enable or disable multicast and broadcast.</p> <ul style="list-style-type: none"> • Disabled • Enabled • Enabled with Proxy ARP enabled
Convert IP multicast to unicast	<ul style="list-style-type: none"> • When set to “Disabled”: none of the multicast package will be converted; • Passive mode: AP will never initiatively broadcast IGMP queries, and the IGMP snooping item will be aged out 300 seconds after it is registered, which may result in the failure of forwarding multicast data. • Active mode: AP will initiatively broadcast IGMP queries to keep updating of the IGMP snooping items.
Enable Voice Enterprise	<p>Check to enable/disable Voice Enterprise. The roaming time will be reduced once enable voice enterprise.</p> <ul style="list-style-type: none"> • The 802.11k standard helps clients to speed up the search for nearby APs that are available as roaming targets by creating an optimized list of channels. • When the signal strength of the current AP weakens, your device will scan for target APs from this list. When your client device roams from one AP to another on the same network, 802.11r uses a feature called Fast Basic Service Set Transition (FT) to authenticate more quickly. FT works with both pre-shared key (PSK) and 802.1X authentication methods. • 802.11v allows client devices to exchange information about the network topology, including information about the RF environment, making each client network aware, and facilitating overall improvement of the wireless network. <p><i>Note: 11R is required for the enterprise audio feature, 11V and 11K are optional. This field is available only when “Security Mode” is set to “WPA/WPA2” or “WPA2”.</i></p>
Enable 802.11r	<p>Check to enable 802.11r.</p> <p>This field is available only when “Security Mode” is set to “WPA/WPA2” or “WPA2”.</p>
Enable 802.11k	Check to enable 802.11k
Enable 802.11v	Enable or disable 802.11v
ARP Proxy	This option will enable GWN device to answer the ARP requests from its LAN for its connected Wi-Fi clients. This is mainly to reduce the airtime consumed by ARP Packets
Enable U-APSD	This option will allow the user to enable/disable the Unscheduled Automatic Power Save Delivery feature.

Wireless LAN

Global Radio Settings

On this page, users can edit the frequency band 2.4GHz or 5GHz that can be used by devices using Wireless LAN also general features can be configured here like Band Steering, Client Steering, Airtime Fairness, etc.




Global Radio Settings

For more details, please visit [GWN Management Platforms – User Guide \(Global Radio Settings\)](#)

Mesh

In Mesh Network, the wireless connection is established between multiple APs, which is used to pass-through data traffic rather than client association. Each AP will evaluate the performance of the wireless channel based on several factors and choose one or multiple appropriate APs to set up the connection.




Mesh

Enable Mesh	Enable or disable Mesh.
Scan Interval	The time period before a scan for new APs is triggered.
Wireless Cascade	The maximum number of wireless cascade which are allowed.

For more details please visit [GWN76xx – User Manual \(Mesh\)](#)

LAN


On this tab, the user can add/edit VLANs or configure the global switch settings that affect all the added GWN switches.




LAN tab

Basic LAN Settings

This page shows all the created VLANs as well as the Default VLAN (Default LAN), click on the LAN created to edit it or click on the "Plus" icon at the bottom to create a new LAN (VLAN).




Basic LAN Settings



Add/Edit LAN

Global Switch Settings

Global Switch Settings allow the user to configure the general settings for all the GWN78XX switches which have been added to the account, instead of configuring the settings individually for each switch.




Global Switch Settings

Radius Authentication	
Radius Profile	Select a Radius server or click Add New RADIUS
Voice VLAN	
Voice VLAN	Toggle voice VLAN on/off.
Multicast	
IGMP Snooping VLAN	Select the IGMP Snooping VLAN.
MLD Snooping VLAN	Select the MLD Snooping VLAN.
Unknown Multicast Message	Configures how the switch (IGMP Snooping/MLD Snooping) handles packets from unknown groups.
DHCP Snooping Settings	
DHCP Snooping	Toggle DHCP Snooping on/off
802.1X	
Guest VLAN	Configures whether to enable the guest VLAN function for the global port.
Other	
Jumbo Frame	Enter the size of the jumbo frame. Range: 1518-10000
Black Hole MAC Address	Select a Black Hole MAC Address from the list or click Add New MAC group

Global Switch Settings

Internet

Internet configuration like adding/configuring WAN ports or configuring Load-balancing/backup (Failover) between the WANs port are found here, these configurations are located under the **Settings tab** → **Internet**.




Internet tab


WAN

In this section, the user can add WAN (router WAN port or a device group) or edit previously created WAN ports and the number of WAN ports is determined by how many GWN routers are added/adopted to GWN.Cloud/GWN Manager accordingly.

To add/edit a WAN, please navigate to **Settings tab** → **Internet** → **WAN**.



WAN list




Add/Edit WAN


For more details please visit [GWN Management Platforms – User Guide \(WAN\)](#)

Internet Source

In this section of internet configuration, under internet source, the user can configure load balancing or backup (Failover) between the previously added WANs. Either click on the entry or “**Configure icon**” to edit previously added internet sources or click on “**Add**” button to add a new one, refer to the figure below:



Internet Source list



Add/Edit an Internet Source

For more details, please visit [GWN Management Platforms – User Guide \(Internet Source\)](#)


VPN

GWN Management supports many VPNs including PPTP, IPSec (support auto networking mode), OpenVPN® and WireGuard®. On GWN app, the user is able to configure:


- **PPTP**: supports client and server.
- **IPSec (Site-to-Site)**: supports manual and auto mode.
- **OpenVPN®**: supports client and server.

GWN Management supports more than one GWN router with single or multi-WAN on the same network, thus when configuring a VPN it’s important to specify which router (WAN/Device group) and interface will be used.


To add a new VPN or a VPN user, please navigate to **Settings tab** → **VPN**, then click on the VPN type as shown in the figures below:



Settings tab



VPN screen




VPN – add VPN

For more details, please visit [GWN Management Platforms – User Guide \(VPN\)](#)


Firewall & Security

Firewall & Security screen combines all the related configuration related to firewall and security, split into 4 sections (Port Forwarding, Wired Firewall Rules, Wireless Firewall Rules and Rogue AP).

Navigate to **Settings screen** → **Firewall & Security**, then click on an entry to configure the corresponding option.




Settings screen




Firewall & Security screen

Port Forwarding

Port forwarding is redirecting the communication request from one address and port to another one address and port. A source IP Address and port will be mapped to a Destination IP Address, port and Group.



Port Forwarding screen



Add Port Forwarding


Wired Firewall Rules

From this screen, the administrator can Accept, Reject or Drop wired traffic using inbound rules or forwarding rules,


- **Accept:** To allow the traffic to go through.
- **Deny:** A reply will be sent to the remote side stating that the packet is rejected.
- **Drop:** The packet will be dropped without any notice to the remote side.

Note:


Wired firewall rules apply only to Routers.



Wired Firewall Rules screen



Add Wired Firewall Rule






Wired Firewall Rule – Policy

Wireless Firewall Rules

This screen does allow users to control the outgoing and incoming traffic from clients connected to the adopted/paired GWN devices by manually setting up policies to either **deny or permit** the traffic for wireless traffic based on protocol type and by specifying SSIDs and destinations.


Note:

Wireless firewall rules apply only to AP.



Rogue AP

GWN Cloud and GWN Manager offer the ability to prevent malicious intrusion to the network and increases the wireless security access of clients when introducing Rogue AP detection feature to the adopted/paired GWN devices. The detected devices will be listed with all the details under **“Alerts”** page for further intervention.




Rogue AP

For more details, please visit [GWN Management Platforms – User Guide \(Firewall & Security\)](#)


Profiles

The profiles screen contains some common configuration for GWN devices like **Port Profile, MAC Groups, Bandwidth rules, PPSK and Certificate.**

Navigate to **Settings screen** → **Profiles**, then click on an entry to configure the corresponding option.



Settings screen




Profiles screen

Port Profiles


Port profiles is a convenient way to provision a GWN device (ex: **GWN switches or a GWN router**) interfaces easily. Name a profile then select the relevant configurations, like VLAN, Rate, Speed limit, LLDP etc. Also for security we can enable Storm control, Port Isolation, Port Security and 801.1X Authentication.

Note:

A VLAN is also considered as a port profile.



Port Profile screen




Add Port Profile

Note:


Feature comparison table for router and switch is available at **About** → **Device Comparison** either on GWN.Cloud or GWN Manager.

MAC Groups

The user can create a group of MAC addresses that can be used for example on GWN switches with the feature of **Black Hole MAC Address** under **Settings screen** → **LAN** → **Global Switch Settings** to block these addresses.




MAC Groups screen




Add MAC Group

Bandwidth Rules

Bandwidth rules feature can be used with a wireless LAN (Wi-Fi or SSID) to limit bandwidth per client or SSID under **Settings screen** → **Wi-Fi** → **Wireless LAN**.



Bandwidth Rules screen




Add Bandwidth Rule

Private Pre-Shared Key (PPSK)


PPSK (Private Pre-Shared Key) is a way of creating Wi-Fi passwords per group of clients instead of using one single password for all clients. Then this PPSK group can be used with a wireless LAN (Wi-Fi or SSID) to grant access to clients under **Settings screen** → **Wi-Fi** → **Wireless LAN**.

1. Click on "+" button to create a PPSK Group.
2. Click on "+" button to create a PPSK.
3. Select Manual or Auto (specify number of PPSKs, name prefix, password ... etc).


Please refer to the figures below:



PPSK screen



Add PPSK Group




Add PPSK


Certificate

In this section, the user can create CA, Client and Server certificates that can be used with OpenVPN either for client or server side.

Click on **"Add CA Certificate"** or **"Add Certificate"** button under CA Certificate or Certificate tab.



Certificates screen




Add Certificate

For more details, please visit [GWN Management Platforms – User Guide \(Profiles\)](#)


System

On the system screen as shown below, the user can configure Country/Region, time, LED ... under General, also URL Access log, Guest Information, NAT and SNMP.

Navigate to **Settings screen** → **System**.




Settings screen



System screen

General

In this section, General configuration can be set like time zone, Device password ... etc. Please refer to the figure and table below:



System – General

Country/Region	Select the country or region from the drop-down list. This can affect the number of channels depending on the country standards.
Timezone	Configure time zone for GWN APs. Please reboot the device to take effect.
Auto Sync Time	If enabled, all managed devices' system times will be synced with GWN Cloud
AP Login Password	Sets the AP login password with up to 8 characters. Alphanumeric characters and special characters - _ are supported

Device Password	Set the devices SSH remote login password other than APs, which is also the device web login password.
LED	Select whether to always turn ON or OFF the LEDs on the APs or apply a schedule for this function.
Reboot Schedule	Once scheduled, the current network will not work for a while during the scheduled period.
Enable Client Connection Event	When enabled, then Client connects/disconnects events are listed under Devices → GWN device → Info page.
Presence API	Once enabled, will detect and collect wireless device info. near the AP, which can be used for device positioning, pedestrian flow monitoring and so on.
Automatically add to SSIDs	GWN devices will be added to SSID automatically

System – General


URL Access Log

Administrators can easily configure the platform to record, monitor and maintain a log of all the websites visited by the clients connected to the paired GWN devices.

The platform System will send these logs via Email to the configured Log Receiver in a form of downloadable link providing a CSV file format containing all the websites logs visited for each client during the defined period (daily, weekly or monthly basis).

In order to enable this feature, follow below steps:

1. Go under “**Settings screen** → **System** → **URL Access Log section**” and enable URL Access Log field, this will configure the GWN management platform (GWN.Cloud or GWN Manager) to start recording the websites logs visited by the clients.
2. The option “**Group Metric by Main Domain**” can be also enabled then the user can configures the top domains to be merged. This will merge the page views for the configured domains. The regular top domains will automatically merge without any configuration (such as. com).
3. Enable Export URL Access Log.
4. Administrators can choose to set the Email Frequency to be generated either on a daily, weekly or monthly basis.
5. Configure the URL Log Receiver Email.




System – URL Access Log

Guest Information

If enabled, the server will periodically send out the guests log download link based on the configured email settings. In order to enable this feature, follow below steps:

1. Go under “**Settings screen** → **System** → **Guest Information section**” and enable Guest Information field.
2. Choose to set the Email Frequency to be generated either on a daily, weekly or monthly basis.
3. Configure the Email Receiver.




System – Guest Information

NAT Pool

Users can use this feature in order to set an address Pool from which the clients that are connected to the adopted/paired devices will acquire their IP address in that way GWN devices will act as a light weight router.

Note:

This option cannot be enabled when Client Assignment IP is set to Bridge mode.




System – NAT Pool

SNMP

This section lists the SNMPv1, SNMPv2c, and SNMPv3 options available to integrate the adopted/paired GWN devices with enterprise monitoring systems.

Users can enable SNMP feature under **Settings screen** → **System** → **SNMP**.



System – SNMP

For more details, please visit [GWN Management Platforms – User Guide \(System\)](#)

EXPERIENCING GWN APPLICATION

Please visit our Website: <http://www.grandstream.com> to receive the most up-to-date updates on firmware releases, additional features, FAQs, documentation, and news on new products.

We encourage you to browse our [product-related](#) documentation, FAQs, and [User and Developer Forum](#) for answers to your general questions. If you have purchased our products through a Grandstream Certified Partner or Reseller, please contact them directly for immediate support.

Our technical support staff is trained and ready to answer all your questions. Contact a technical support member or [submit a trouble ticket online](#) to receive in-depth support.

Thank you again for using the Grandstream GWN Cloud application, it will be sure to bring convenience to both your business and personal life.

CHANGE LOG

This section documents significant changes from previous versions. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

GWN Application Version 1.0.3.14

- Added GWN Device Discovery and Speed Test Tools [[Tools](#)]
- Added PPTP, IPSec(support auto networking mode), OpenVPN® [[VPN](#)]
- Added Guest under Clients [[Clients](#)]
- Added 12-hours WAN ports health monitoring [[Internet Health](#)]
- Added Cloud DDNS service to generate domain for managed WAN [[WAN](#)]
- Added VLAN interface configuration under router configuration [[Devices](#)]

- Added new alerts, and improve the layout [[Alert](#)]
- Added VLAN ID info under Client page [[Client](#)]
- Support multiple routers on one network [[Devices](#)]
- Support Device Password under System page [[System](#)]

GWN Application Version 1.0.1.11

- Support GWN Router (GWN7052 & GWN7062) unified management
- Support GWN Switch
- New UI design
- Redesigned dashboard
- New alerts design and support more alert events
- Optimized clients display, integrate the old known clients function into clients page
- Optimized SSID security type

GWN Application Version 1.0.0.19

- Added support for "Local Server".

GWN Application Version 1.0.0.2

- This is the initial version of the GWN Cloud Application for Android.

Android is a trademark of Google LLC.
